

Table of Contents

	Page
Section 2.23. Weights	2-93
A. Application	2-93
A.1. General.....	2-93
A.2. Exceptions.....	2-93
A.3. Additional Code Requirements.	2-93
S. Specifications	2-93
S.1. Material.....	2-93
S.2. Design.....	2-93
S.2.1. Surface.....	2-93
S.2.2. Ring.....	2-93
S.3. Adjusting Material.....	2-93
S.4. Marking Requirements.....	2-93
S.4.1. General.....	2-93
S.4.2. Apothecaries' Weights.....	2-93
S.4.3. Troy Weights.....	2-93
S.4.4. Metric Weights.....	2-93
S.4.5. Carat Weights.....	2-93
S.4.6. Counterpoise Weight.....	2-93
N. Notes	2-94
N.1. Testing Procedures.....	2-94
T. Tolerances	2-94
T.1. In Excess and In Deficiency.....	2-94
T.2. On Avoirdupois Weights.....	2-94
T.3. On Metric Weights.....	2-95
T.4. On Carat Weights.....	2-95
T.5. On Apothecaries and Troy Weights.....	2-96

THIS PAGE INTENTIONALLY LEFT BLANK

Section 2.23. Weights

A. Application

A.1. General. – This code applies to commercial weights; that is, weights used in connection with commercial weighing devices.

A.2. Exceptions. – This code does not apply to test weights or to other “standards” of mass.

A.3. Additional Code Requirements. – In addition to the requirements of this code, Weights shall meet the requirements of Section 1.10. General Code.

S. Specifications

S.1. Material. – The material used for weights shall be as follows:

- (a) Weights of 6 grams or 100 grains and larger shall be made of a metal, or a metal alloy, not softer than brass.
- (b) Weights of less than 6 grams or 100 grains may be made of aluminum, but shall not be made of iron or of unplated steel, except stainless steel.

S.2. Design.

S.2.1. Surface. – The surface of a weight shall be smooth and shall not be coated with thick, soft, or brittle material. A weight of more than 2 grams or 30 grains or shall not have sharp edges, points, or corners.

S.2.2. Ring. – A ring on a weight shall not be split or removable.

S.3. Adjusting Material. – Adjusting material shall be securely positioned and shall not project beyond the surface of the weight.

S.4. Marking Requirements.

S.4.1. General. – A weight shall be marked to show clearly its nominal value, which shall include identification of the unit; however, the nominal value of a weight of 2 grams or 30 grains, or less, may be designated by dots, lines, figures, distinctive shape, or other appropriate means.

S.4.2. Apothecaries’ Weights. – On apothecaries’ dram, ounce, and pound weights, the letters “ap” shall be used in combination with the nominal value and the appropriate abbreviation of or symbol for the unit.

S.4.3. Troy Weights. – On troy ounce and pound weights, the letter “t” shall be used in combination with the nominal value and the appropriate symbol of the unit.

S.4.4. Metric Weights. – On metric weights, the symbols “kg,” “g,” and “mg” shall be used in combination with the nominal value of kilograms, grams, and milligrams, respectively.

S.4.5. Carat Weights. – On carat weights, the letter “c” shall be used in combination with the nominal value.

S.4.6. Counterpoise Weight. – A counterpoise weight shall be marked to show clearly both its nominal value and the value it represents when used on the multiplying-lever scale for which it is intended.

N. Notes

N.1. Testing Procedures. – Commercial weights should be tested on a precision balance using standard weights, the errors of which, when used without correction, do not exceed 1/3 of the smallest tolerance to be applied. (Also see Appendix A, Fundamental Considerations, paragraphs 3.2. Tolerance for Standards and 3.3. Accuracy of Field Standards.)

T. Tolerances

T.1. In Excess and In Deficiency. – The tolerances hereinafter prescribed shall be applied equally to errors in excess and errors in deficiency.

T.2. On Avoirdupois Weights. – The maintenance tolerances shall be as shown in Table 1. Maintenance Tolerance for Avoirdupois Weights. Acceptance tolerances shall be one-half the maintenance tolerances.

Table 1. Maintenance Tolerance for Avoirdupois Weights						
Maintenance Tolerance						
Nominal Value	Equal-Arm Weights		Counterpoise Weights			
			For scales with multiples of less than 1000		For scales with multiples of 1000 or over	
oz	grains	mg	grains	mg	grains	mg
1/64	0.1	6				
1/32	0.3	19				
1/16	0.4	26				
1/8	0.5	32				
1/4	1.0	65				
1/2	1.5	97	1.0	65		
1	1.7	110	1.0	65		
2	2.0	130	1.0	65		
3	2.0	130	1.5	97		
4	3.0	190	1.5	97	1.0	65
5	3.5	230	1.5	97	1.0	65
6	3.5	230	1.5	97		
8	4.0	260	2.0	130	1.5	97
10	4.0	260	2.5	160	2.0	130
12	5.0	320	2.5	160	2.0	130
lb	grains	mg	grains	mg	grains	mg
1	5.0	320	3.0	190	2.5	160
2	7.0	450	6.0	390	4.0	260
3	9.0	580	9.0	580	5.0	320
4	11.0	710	11.0	710	6.0	390
5	15.0	970	12.0	780	6.5	420
6	17.0	1190				
7	19.0	1200				
8	21.0	1400	15.0	970	9.0	580
9	23.0	1500				
10	25.0	1600	18.0	1160	10.0	650
15	28.0	1800				
20	30.0	1900				
25	35.0	2300				
30	40.0	2600				
40	45.0	2900				
50	50.0	3200				

This publication is available free of charge from <https://doi.org/10.6028/NIST.HB.44-2025>

T.3. On Metric Weights. – The maintenance tolerances shall be as shown in Table 2. Maintenance Tolerances for Metric Weights. Acceptance tolerances shall be one-half the maintenance tolerances.

T.4. On Carat Weights. – The maintenance tolerances shall be as shown in Table 2. Maintenance Tolerances for Metric Weights. Acceptance tolerances shall be one-half the maintenance tolerances.

Table 2. Maintenance Tolerances for Metric Weights			
Nominal Value (mg)	Maintenance Tolerance (mg)	Nominal Value (g)	Maintenance Tolerance (mg)
5 or less	0.1	1	4
10	0.3	2	6
20	0.4	3	8
30	0.6	5	10
50	0.8	10	15
100	1.0	20	20
200	1.5	30	30
300	2.0	50	40
500	3.0	100	70
		200	100
		300	150
		500	175
Nominal Value (kg)	Maintenance Tolerance (mg)	Nominal Value (carats)	Maintenance Tolerance (mg)
1	250	0.25*	0.6
2	400	0.5**	1.0
3	500	1.0	1.5
5	800	2.0	2.0
10	1000	3.0	3.0
20	1500	5.0	4.0
		10.0	6.0
		20.0	10.0
		30.0	12.0
		50.0	15.0
		100.0	25.0
		*25 points or less	
		**50 points	

T.5. On Apothecaries and Troy Weights. – The maintenance tolerances shall be as shown in Table 3. Maintenance Tolerances for Apothecaries' and Troy Weights. Acceptance tolerances shall be one-half the maintenance tolerances.

Table 3.					
Maintenance Tolerances for Apothecaries' and Troy Weights					
Nominal Value	Maintenance Tolerance		Nominal Value	Maintenance Tolerance	
grains	grains	mg	oz	grains	mg
1	0.01	0.6	1	0.4	25.0
2	0.02	1.3	2	0.6	40.0
3	0.03	2.0	3	1.0	65.0
5	0.03	2.0	4	1.5	100.0
10	0.04	2.5	5	1.6	105.0
20	0.06	4.0			
scruples	grains	mg	oz	grains	mg
1	0.06	4.0	6	1.8	115.0
2	0.10	6.5	7	1.9	125.0
			8	2.0	130.0
			9	2.1	135.0
			10	2.2	145.0
dr	grains	mg	oz	grains	mg
0.5	0.07	4.5	11	2.4	155.0
1.0	0.10	6.5	12	2.5	160.0
2.0	0.20	13.0	20	2.9	190.0
3.0	0.30	20.0	30	3.7	240.0
4.0	0.40	25.0	50	5.4	350.0
5.0	0.50	30.0			
6.0	0.60	40.0			
dwt	grains	mg	oz	grains	mg
1	0.06	4.0	100	7.7	500.0
2	0.10	6.5	200	12.3	800.0
3	0.15	10.0	300	15.4	1 000.0
4	0.20	13.0	500	23.1	1 500.0
5	0.30	20.0	1 000	38.6	2 500.0
10	0.40	25.0			

THIS PAGE INTENTIONALLY LEFT BLANK